Quick Installation Guide

Thank you for purchasing SS2GD8IP!

8-port Gigabit L2 Managed PoE Switch with 2 combo RJ45/SFP ports

Packing List

Before you start using the appliance, please verify that the package contains the following items:

- SS2GD8IP, the 8 port Gigabit Layer 2 Switch with POE
- AC Power Cord
- Console Cable
- User Manual CD
- Mounting Accessory (for 19” Rack Shelf) (Optional)

Power Requirements

Voltage	:	100~240 VAC
Frequency	:	50~60 Hz
Consumption	:	65W (SS2GD8IPH)
	:	130W (SS2GD8IP)

Quick Installation Guide

1. Install the switch in the rack with mounting accessory.
2. Connect the switch to an AC power source.
3. The port 1–8 connector are RJ45 pots, please use Category 5 UTP cable to connect the switch and client station.
4. The port 7~ 8 are shared ports for RJ45/SFP combo, auto-sensing is supported.
5. The default default values of the switch are as follows:

IP Address	: 192.168.1.1
Subnet Mask	: 255.255.255.0
Default Gateway	: 192.168.1.254
Username	: admin
Password	: admin

User can use web to configure the switch with the default IP address and password in the first configuration.
Please refer to User Manual comes with the CD for details on the setting of parameters. User’s manual is filed under the path: \manual of the CD-ROM.

To get more help for technical support, please visit http://www.amer.com/support.